

we recommend using the "Windows Hypervisor Platform" for Hardware Acceleration, because Intel does not support the HAXM Feature any more.

To turn on the "Windows Hypervisor Platform" run the command "optionalfeatures" in a cmd window and select the option "Windows Hypervisor Platform". Restart of the PC is needed.

The above mentioned error about the socket binding may be caused by a still running qemu process. To be shure not process is still running, try to stop all "qemu-system-x86_64.exe" (task manager /details). Then try to restart the virtual control.

Regards,

Oliver